Part #2007231 Fits 2000-2005 PT Cruiser, including turbo **NOTE:** this cat-back 2-1/2" system has a single outlet Heartthrob exhaust systems are manufactured by Heartthrob Exhaust--Litchfield, MN

Ha	urdware:
1)	2-1/4" clam

amp	1)	straight front extension pipe (2-1/4" i.d./2-1/2" o.d.)#2007231
-		

2) 2-1/2" clamps 1) 2-1/2" middle extension pipe#PTC-1

1) 2-1/2" over the axle pipe/muffler/stainless tip# PTC-2

INSTRUCTIONS: **NOTE:** DO NOT TIGHTEN ANY CLAMPS UNTIL THE LAST STEP!!

1) Remove the exhaust system after the clamp behind the converter, leaving the O.E. rubber hanger mounts on the vehicle.

2) Install the shrunk end (2-1/4" i.d.) of the straight front extension pipe to the converter pipe. Be sure to line up the notch on the pipe to the pin on the converter pipe. Use a 2-1/4" clamp to connect the two pipes.

3) Put the middle extension pipe to where it will run. Install the wire hanger on the middle extension pipe to the O.E. rubber mount near where the middle extension pipe runs. Use a 2-1/2" clamp to attach the 2-1/2" middle extension pipe to the straight front extension pipe.

4) Install the front hanger of the muffler to the O.E. rubber mount near where the muffler will be positioned.

5) Install the inlet of the 2-1/2" over the axle pipe/muffler/stainless tip to the 2-1/2" middle extension pipe. Connect the two pipes using a 2-1/2" clamp. Attach the rear hanger to the O.E. rubber mount at the rear of the vehicle.

6) Tighten all clamps and check for clearance of all brake and fuel lines, and clearance of the frame and of chassis components.



Heartthrob exhaust systems are manufactured by Heartthrob Exhaust--Litchfield, MN

Email us at mike@heartthrobexhaust.com with any questions. www.heartthrobexhaust.com 320-693-0222

#2007231

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL THIS EXHAUST PRODUCT AT HOME, BE WARNED THAT PLEASURE CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE WHILE THE INSTALLATION PROCEEDS.

Limitation of liability--Disclaimers: The regulation of emissions production, noise levels and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns and counties.

The manufacturer makes no warranties of merchantability, of fitness for a particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations or ordinances in the states where they may be sold to the ultimate purchaser, the consumer.

The entire risk as to the conformity of this product in any such state and as to repair, should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, and or repair.

The foregoing statement limits the liability of the manufacturer.



BUILD SHEET FOR: PT CRUISER PART# 2007231

1) straight front extension pipe (2-1/4" i.d./2-1/20.d.)#2007231

1) 2-1/2" middle extension pipe#PTC-1

____1) 2-1/2" over the axle pipe/muffler/stainless tip# PTC-2

1) HARDWARE KIT

INSPECTED BY:

DATE:

INSPECTED BY:

DATE: _____

BUILD SHEET FOR: PT CRUISER PART# 2007231

____1) straight front extension pipe (2-1/4" i.d./2-1/2o.d.)#2007231

- 1) 2-1/2" middle extension pipe#PTC-1
- 1) 2-1/2" over the axle pipe/muffler/stainless tip# PTC-2
- 1) HARDWARE KIT

INSPECTED BY:

DATE:

INSPECTED BY:

DATE: _____

BUILD SHEET FOR: PT CRUISER PART# 2007231

1) straight front extension pipe (2-1/4" i.d./2-/20.d.)#2007231

- ____1) 2-1/2" middle extension pipe#PTC-1
- __1) 2-1/2" over the axle pipe/muffler/stainless tip# PTC-2

____1) HARDWARE KIT

INSPECTED BY:

DATE: ______ INSPECTED BY: _____

DATE: _____